

Code-Pairing

Bus-Scan 300 RF

Installation Guide

Operation Guide



Table of Contents

- 2 Return Policy and Contact Information
- 3 Supplied Components
- 4 **Bus-Scan** 300 Features and Functions
- 5 **Bus-Scan** 300 System Operation
- 6 Required Tool and Installation Instructions
- 7 Installation Instructions and System Testing
- 8 **Bus-Scan** 300 Wiring Instructions
- 9 Troubleshooting
- 10 RF Receiver / Transmitter
- 11 Specifications and Replacement Parts
- 12 Warranty

Return Policy

For Warranty Service, call Robotics Technologies, Inc. Customer Service to obtain an RMA (Return Materials Authorization), and then return the product postage prepaid to Robotics Technologies, Inc. The RMA number should be written clearly on the outside of the box. Please enclose a brief explanation of the problem, so that we can more efficiently diagnose your item and ensure timely service.

Contact Information

For support, please contact Robotics Technologies, Inc. or a Robotics Technologies Authorized Dealer.

Robotics Technologies, Inc.

20655 Burl Court


Joliet, IL 60433

Phone (800) 995-6056

Fax (815) 722-7655

Website: www.roboticstech.com


Supplied Components



The following components are included with the **Bus-Scan 300**

- 1 **Bus-Scan** 300 Control Unit
- 2 Remote transmitter
- 3 # 8 x 3/8" sheet metal screws (4)
- 4 Service override key
- 5 Wiring harness
- 6 **Bus-Scan** 300 installation and operations guide
- 7 Drilling template

Bus-Scan 300 Features and Functions



1 Service Switch

Deactivates the **Bus-Scan** 300. This feature is used when the vehicle is being serviced. The key removes only in the active position

2 Service indicator light

Blinks when the **Bus-Scan** 300 is in the service mode

3 RF Link indicator light

Lights when the coded signal is received from the **Bus-Scan** Transmitter

4 Armed indicator light

Lights when the system is armed

5 Transmitter-Receiver Pairing Hole

Used to match the transmitter and receiver codes

6 Option Select Switches

Selects different time-out lengths and controls the operation the RF receiver

7 Main Harness Receptacle

8 Optional Siren Receptacle

Bus-Scan 300 System Operation

The **Bus-Scan** 300 system operates in the following sequence:

- 1) The bus is started, and the route begins.
- 2) After the route is completed and the bus is turned off, the **Bus-Scan** 300 emits a reminder tone.
- 3) The driver proceeds to the rear of the bus, checking for sleeping children.
- 4) The driver pushes the deactivation push-button.
- 5) The **Bus-Scan** 300 is deactivated.
- 6) The driver exits the vehicle. If the driver exits the vehicle without deactivating the **Bus-Scan** 300, the horn will sound after the preset time-out. (Alarm Condition).

The **Bus-Scan** 300 can be armed in 3 different ways:

- 1) **Classic Mode:** The **Bus-Scan** 300 will activate on every ignition cycle. To use this mode, connect the Blue wire to a constant 12v source.
- 2) **Stop Arm Mode:** The **Bus-Scan** 300 will arm only after the stop arm circuit has been activated. To use this mode, connect the Blue wire to the Stop Arm Circuit and set the option DIP switch #3 to Off.
- 3) **Stop Arm Mode with Field Trip Timer:** The **Bus-Scan** 300 will arm after the stop arm circuit has been activated, or the bus has been running for 10 minutes. To use this mode, connect the Blue wire to the Stop Arm Circuit and set the option DIP switch #3 to On.

To Cancel the Alarm

- 1) The driver must cycle the Ignition off, to on, to off.
- 2) The driver must follow the proper deactivating sequence (steps 3-6 above)


The **Bus-Scan** 300 is equipped with a tamper feature that will alarm if the deactivation push-button is tampered with.

A tamper condition exists if the deactivation push-button is activated during the cycling of the ignition from on to off.

To Cancel the Tamper Alarm

- 1) The Tamper condition must be removed
- 2) The driver must cycle the Ignition off to on to off
- 3) The driver must follow the proper deactivating sequence (steps 3-6 above)

Required Tools



The following tools are required to install the **Bus-Scan 300**

- | | |
|-----------------------------|----------------|
| 1 Electric drill | 5 Center punch |
| 2 1/8" drill bit | 6 Hammer |
| 3 1/2" drill bit | 7 Multi meter |
| 4 Phillips head screwdriver | |

Installation Instructions

Mounting the **Bus-Scan 300**

- 1 Locate a suitable location near the driver's compartment
- 2 Using the supplied Drilling Template, center punch and drill according to the template
- 3 Wire the **Bus-Scan 300** according to the wiring instructions
- 4 Attach the **Bus-Scan 300** to the bus using 2 #8 x 3/8" sheet metal screws.

Pair the Remote Transmitter and **Bus-Scan 300** Control Unit

- 1 Note the Pairing Hole on the front of the main unit (Page 4, Item 5). Insert a paper clip into the hole to activate Pairing Mode (the RF Link indicator will start flashing).
- 2 Within 15 seconds, press the Remote Transmitter button to pair. Upon successful pairing, the RF Link indicator will stop flashing.


Mount the Remote Transmitter

- 1 Locate a suitable location where the Remote Transmitter may be mounted.
- 2 Center punch and drill the mounting holes
- 3 Attach the Remote Transmitter to the vehicle.

Test the Transmitter / Receiver

- 1 Activate the Remote Transmitter
- 2 Check the RF link indicator on the **Bus-Scan 300** Unit.
- 3 If the RF link indicator is not steady, reorient the transmitter for the strongest signal.

Bus-Scan 300 Wiring Instructions



- 1) Connect the Red wire to a constant +12v.
- 2) Connect the Black wire to chassis ground.
- 3) Connect the Brown wire to the ignition circuit.
- 4) Connect the Green wire to chassis ground.
- 5) Connect the Yellow wire to the horn switch (button).
- 6) Connect the Blue wire (Arming Mode)
 - a) Connect the Blue wire to +12v for **Bus-Scan** Classic operation (Armed whenever the Ignition is on)
 - b) Connect the Blue wire to the stop arm activation switch for Stop Arm Arming. The system will be Armed after the stop arm has been activated

IMPORTANT!!

Vehicle must be equipped with a **Horn Relay**. If your Vehicle does not have a Horn Relay, a Horn Relay Kit Part No. 102893 is available.

System Testing

Normal Test

- 1) Turn the Ignition on and wait for the Armed Led to Illuminate
- 2) Turn the ignition off and the reminder tone will sound
- 3) Deactivate using Remote Transmitter the reminder tone and Armed LED will shut off.

Alarm Test

- 1) Repeat Steps 1 and 2 above
- 2) Wait for 60 seconds then the horn will sound
- 3) Recycle Ignition and deactivate using Remote Transmitter

Troubleshooting

Reminder tone not sounding after ignition on/off cycle

- 1 Check Red wire for a constant +12v
- 2 Check Brown wire
 - a) +12v when Ignition is on
 - b) 0v when ignition is off
- 3 An arming mode other than Classic has been selected:
 - a) The Blue wire is disconnected
 - b) The Blue wire is connected to the stop arm control (Stop Arm Arming)

Armed System Disarms after Ignition Cycle

- 1 A power interruption or brown out power condition occurred
 - a) Connect the Red wire to another 12v power source

Horn Sounds when ignition is turned off

- 1 Tamper Condition.
 - a) Remote Transmitter button pushed during ignition cycling.

Remote Transmitter will not deactivate the system

- 1 Transmitter battery may need replacement.
- 2 Reorient the transmitter for a "clear path" to the receiver.
- 3 Ensure that the transmitter and receiver are paired.

Alarm will not sound horn

- 1 Horn Switch Wire (Yellow) improperly wired.
- 2 Horn Switch Wire (Yellow) Fuse open.
- 3 Horn Ground Wire (Green) improperly wired.

Horn Switch Fuse Blows

- 1 Vehicle does not have a Horn Relay.
 - a) Install Horn Relay Kit Part No. 102893.
- 2 Horn Switch Wire (Yellow) improperly wired.

Troubleshooting Continued

Reminder Tone Sounds 5 times whenever the vehicle is turned on

This is normal when the **Bus-Scan** 300 is in Service Mode. The beeps remind the driver that the **Bus-Scan** 300 is in Service Mode.

The range of the keyless entry system decreased

- 1 The **Bus-Scan** and the vehicle are both using the 315Mhz Frequency.
 - a) Locate the Option DIP Switch (3 Position Switch) on the back of the **Bus-Scan** 300. Refer to the diagram and chart below
 - b) Slide switch #3 on the to the ON position.
Note the RF Link will only be active during the **Bus-Scan** Time-Out


I want a longer or shorter Time-Out

The **Bus-Scan** 300 can be set for a 1 or 5 minute delay.

- 1 To change the delay
 - a) Locate the Option DIP Switch (3 Position Switch) on the back of the **Bus-Scan** 300
 - b) Slide switch #1 to the desired value.
Off=1 Minute On=5 Minutes

Bus-Scan 300 Option Setting

To change the time-out delay and receiver option, change the DIP switch settings according to the chart



1	Time-Out	2	Auto Arming	3	Remote Option
Off	1 Minute	Off	No Auto Arming	Off	Full Time Sensing
On	5 Minutes	On	10 Minute Auto Arming	On	Sensing During Time-Out Only

RF Transmitter / Receiver

The Bus-Scan is equipped with an RF transmitter and receiver. The signal is encoded with a digital code. The code of the transmitter must match the code of the receiver.

To Pair the Remote Transmitter and Receiver:


- 1) Turn the Ignition Switch on
- 2) Locate the Code-pairing hole on the front of the unit (Page 4, Item 5)
- 3) Press a paper clip into the hole to activate pairing. The RF Link will flash.
- 4) Press the Remote Transmitter button within 15 seconds.
- 5) When pairing is complete, the RF Link will turn off

Remote Transmitter Battery:

The **Bus-Scan** remote transmitter is equipped with a 12v alkaline battery. The battery life is over 5 years in normal use; however, we recommend that the battery be replaced at the beginning of each school year

To Replace the Battery:

- 1) Remove the 4 cover screws
- 2) Remove the cover
- 3) Replace the battery (observe polarity)
- 4) Replace the cover
- 5) Replace the 4 cover screws



FCC ID: OF9-1229TXR1

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Model No. BS100TX

Robotics Technologies, Inc Joliet, IL

Made in U.S.A.

Specifications

Bus-Scan 300 Control Unit

Dimensions: Length 4.25" Width 2.25" Height 1.5"
Enclosure Material: Flame Retardant ABS Plastic UL 94-5VA
Electrical System: 12v Negative Ground Fuse @ 2A
Horn Activation: Form A Contact Fuse @ 2 Amp
RF Receiver: 315 Mhz ASK

BS 100TX Remote Transmitter

Dimensions: Length 4.25" Width 2.375" Height 1.0"
Enclosure Material: Flame Retardant ABS Plastic UL 94-5VA
Battery: 12v Alkaline Battery MN21A, GP23A or equivalent
Frequency: 315 Mhz ASK

Replacement Parts and Accessories

<i>Part No.</i>	<i>Description</i>
106029	Bus-Scan 300 RF Coded Control Unit
106032	Bus-Scan BS 100TX Coded Remote Transmitter
103553	12v Alkaline Battery
104546	Bus-Scan RF Wiring Harness
103543	Bus-Scan Service Switch Lock
102799	Bus-Scan Service Switch Key
104569	Bus-Scan 300 RF Parts Kit
104567	Bus-Scan 300 RF Installation and Operations Guide
102893	Bus-Scan Horn Relay Kit
104533	Bus-Scan Siren
104078	Bus-Scan Light Control Module
104186	Bus-Scan Light Control Module for Thomas C2

Warranty

Robotics Technologies, Inc. (RTI) warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of purchase. Its obligation under this warranty is limited to repairing or replacing at its own sole option any such defective products. To obtain service under this warranty you must obtain a Return Material Authorization (RMA) number from RTI. Products must be returned to RTI with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment that has been damaged by accident, negligence or misapplication or has been altered or modified in any way. This warranty applies only to the original purchaser.

The Bus-Scan® Seat Check Reminder is not a security or detection device. It is used as a reminder for the driver to physically check seats.

It is the responsibility of the customer to ensure secure mounting and the continued maintenance thereof. Customer will indemnify RTI and hold it harmless from all actions or litigation arising from misuse of or improper mounting of the Bus-Scan®.

EXCEPT AS PROVIDED HEREIN RTI MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore the aforesaid limitation(s) or exclusion(s) may not apply to purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL RTI BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, RTI is not liable for any costs such as loss of profits or revenue, loss of service, loss of equipment, costs of substitutes, and claims by third parties or otherwise. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

