

## Bus-Scan® BS 300 Wiring Reference

### Chevrolet Suburban

#### Model Year 2015

BS 300 Function/Color	Vehicle Function/Color	Location
<b>Power</b> – Red.	<b>Constant Power</b> – Red/Purple (+)	BCM under driver-dash. Blue 27-pin plug, pin 4
<b>Ground</b> – Black.	<b>Ground</b> – Chassis.	Various
<b>Ignition</b> – Brown.	<b>Ignition</b> – Purple/Black (+)	@ Ignition Switch or BCM, under driver-dash, green 25-pin plug, pin 6
<b>Horn</b> – Yellow.	<b>Horn</b> – Brown/White (-)	BCM, under driver-dash, brown 26-pin plug, pin 22.
<b>Horn Polarity</b> – Green.	<b>Ground</b> – Chassis.	Various.

#### Model Years 2007-2010

BS 300 Function/Color	Vehicle Function/Color	Location
<b>Power</b> – Red.	<b>Constant Power</b> – Red/Black.	@ Fuse Box, Black 40-Pin Plug Pins F1 or E3.
<b>Ground</b> – Black.	<b>Ground</b> – Chassis.	Various
<b>Ignition</b> – Brown.	<b>Ignition</b> – Pink.	@ Ignition Switch or BCM, Light Green Plug, Pin 14.
<b>Horn</b> – Yellow.	<b>Horn</b> – Tan.	@ Horn Switch or BCM, Brown Plug Pin 18.
<b>Horn Polarity</b> – Green.	<b>Ground</b> – Chassis.	Various.

#### Model Year 2006

BS 300 Function/Color	Vehicle Function/Color	Location
<b>Power</b> – Red.	<b>Constant Power</b> – Red.	@ Ignition Switch Harness.
<b>Ground</b> – Black.	<b>Ground</b> – Chassis.	Various.
<b>Ignition</b> – Brown.	<b>Ignition</b> – Pink.	@ Ignition Switch Harness.
<b>Horn</b> – Yellow.	<b>Horn</b> – Black/Yellow to Black.	@ Horn Switch or BCM, Gray Plug, Pin B9.
<b>Horn Polarity</b> – Green.	<b>Ground</b> – Chassis.	Various.

#### Model Years 2003-2005

BS 300 Function/Color	Vehicle Function/Color	Location
<b>Power</b> – Red.	<b>Constant Power</b> – Red & Red/White.	@ Ignition Switch Harness.
<b>Ground</b> – Black.	<b>Ground</b> – Chassis.	Various.

<b>Ignition</b> – Brown.	<b>Ignition</b> – Pink.	@ Ignition Switch Harness.
<b>Horn</b> – Yellow.	<b>Horn</b> – Black/Yellow to Black.	@ Steering Column Harness.
<b>Horn Polarity</b> – Green.	<b>Ground</b> – Chassis.	Various.